Shoelace Length Chart

coolnice.com.au

Most sneakers have 6 holes on each side and typically use **120 cm (47.2")** laces. Shoes vary, so use this chart as a guide.

Best way: measure your old lace. Lay it flat and measure tip to tip, including the plastic ends. Choose the same length, or the next one up.

Full length chart

Holes on one side (eyelet pairs)	Typical shoe	Criss-cross Most common	Straight bar
2	Kids, slip-ons	**80 cm** (31.5")	70 cm (27.6")
3	Kids, low canvas	**90 cm** (35.4")	85 cm (33.5")
4	Low canvas, boat shoes	**100 cm** (39.4")	85 cm (33.5")
5	Low sneakers	**110 cm** (43.3")	100 cm (39.4")
6	Most sneakers	**120 cm** (47.2")	105 cm (41.3")
7	Mid-tops, running shoes	**130 cm** (51.2")	115 cm (45.3")
8	High-tops	**140 cm** (55.1")	120 cm (47.2")
9	High-tops, hiking shoes	**150 cm** (59.1")	135 cm (53.1")
10	Boots	**160 cm** (63.0")	135 cm (53.1")
11	Boots	**170 cm** (66.9")	150 cm (59.1")
12	Tall boots	**180 cm** (70.9")	155 cm (61.0")

Based on sneakers and boots, with eyelets 5 cm (2.0") apart across the laces and 1.6 cm (0.6") apart up the shoe, plus 27.5 cm (10.8") at each end for a bow. Rounded up to the next 5 cm. Shoes vary, so treat these as typical lengths. Between two lengths? Go longer.

From **coolnice.com.au/shoelace-size-chart**. We stock laces in every length from 20 to 180 cm, in 5 cm steps.